

# LIBERTY TASK CHAIRS

## Features and Innovations

### 1. Self-Adjusting Recline

- Intelligent counter-balance recline mechanism automatically provides the right amount of support through the full range of recline motion, regardless of user size and weight
- No recline locks to set/release
- User maintains near constant eye level during recline

### 2. Pivoting Backrest

- Extra motion of the backrest during recline automatically adjusts to the changing needs of the spine
- Provides additional lumbar support as needed

### 3. Form-Sensing Mesh Back

- Tri-panel, non-stretch mesh construction creates body-fitting contours and self-adjusting lumbar support for a customized fit
- Low-abrasion mesh protects clothing

### 4. Contoured Seat Cushion

- Increased contact area reduces pressure points

### 5. Armrest Options


- Adjustable or fixed armrests connect to the backrest instead of the seat so they stay with the body during recline

### 6. Body Fit

- Weight-sensitive recline
- Form-sensing lumbar support
- Seat height
- Seat depth

### 7. Casters

- 3" dual-surface casters roll easily on carpeted floors and quietly on hard floors



## ADJUSTABLE TABLES

Height adjustment permits seated or standing work and allows for a healthy variety of postures throughout the day.

### To Move the Table Up and Down

To move the table up, press and hold the ▲ button. To move the table down, press and hold the ▼ button.

### Set to a Memory Position

Move the table to the desired table height to be saved. Press and release the M button. Then press the desired memory position button (1, 2 or 3) within 10 seconds.

### Move to a Memory Position

Press and hold the saved memory position button (1, 2 or 3) - the table will automatically go up or down to the saved position and stop once it reaches the preset height.

### Change the Display Units

To switch the display between inches or centimeters, press and hold the M button while simultaneously pressing and holding the ▼ button for 5 seconds.

### Troubleshooting

#### Q - The table will not adjust

A - Check that the power is connected properly at the control box and at the outlet. Re-initialize the table.

#### Q - The table moves slowly

A - Check that the power is connected properly at the control box and at the outlet. Re-initialize the table.

#### Q - The table moves in the wrong direction

A - Re-initialize the table.

#### Q - The table moves up on its own

A - Press the up button to stop the table from moving. Re-initialize the table.

#### Q - The table moves down on its own

A - Check if the weight on the table exceeds 200lbs (90kg). If so, remove items to reduce weight maximum to 200lbs (90kg). Re-initialize the table.

